



Rubber Roofing Products

Tack Back™ F-PRIMER

INSTALLATION INSTRUCTIONS

Tack Back™ F-Primer is a black tape primer designed for use with EPDM rubber roofing installations to enhance the performance and bond of EPDM and TPO seam tape. This black tape primer requires initial stirring at the start of each day and periodically throughout the day. It is a fast drying product but is influenced by both temperature and humidity. Strong initial tack allows for immediate bond of tapes to membranes. This product is not intended for use in OTC

Surface Preparation:

All surfaces must be dry and free from oil, grease, talc, dust, dirt, and other foreign materials.

Directions:

Tack Back™ F-Primer should be stirred thoroughly prior to use and then scrubbed into the EPDM surface thoroughly using scrub pads such as Scotch-Brite pads. Change applicator pads frequently and cover an area in excess of the area to be seamed. The use of Seal Trust™ Splice Wash prior to application of this product is recommended on dirty, old membranes to remove all surface contaminations and enhance the performance and bond of EPDM seam adhesives and primers. When used with clean TPO, this primer is a cleaner and primer and the use of Toluene Splice Wash is not required. This product dries black use caution when using with white or colored membranes. Clean up with mineral spirits.

KEEP OUT OF THE REACH OF CHILDREN.



**DANGER! HIGHLY FLAMMABLE
CAUSES SKIN IRRITATION. HARMFUL OR FATAL IF SWALLOWED.
MAY CAUSE DROWSINESS OR DIZZINESS.
IF SWALLOWED, CALL PHYSICIAN IMMEDIATELY.**

Contains: Toluene 108-88-3 Hexane 110-54-3 Heptane 142-82-5 Xylene 1330-20-7
BEFORE USE, REVIEW SAFETY DATA SHEET FOR FURTHER INFORMATION, INCLUDING CHRONIC HEALTH EFFECTS. DO NOT USE WELDING OR CUTTING TORCH ON OR NEAR THIS CONTAINER (EVEN WHEN EMPTY).