



TPO and Rubber Roofing Products

Low Voc Neoprene Bonding Adhesive installation



Seal Trust™ Low VOC Neoprene Bonding Adhesive is designed for use with EPDM and TPO membranes to adhere to insulation boards such as ISO and wood fiber and also to wood, metal, masonry and approved roofing substrates. It may also be used as a general contact bonding adhesive for both vertical and horizontal surfaces. It is especially formulated for use in OTC states with Low VOC requirements. May dry faster than regular bonding adhesives due to the solvent content. May be applied using brush, roller or squeegee and also may be sprayed applied using proper equipment.

Application Instructions:

Recommended application instructions for use in EPDM projects are printed on the container label. Care must be taken to ensure adequate adhesive coverage when using some substrates with irregular surface patterns. Stir well before use. May be warmed to room temperature before use to promote easier application. Apply a thin coat to both intended surfaces and let adhesive “dry” until it is tacky to the touch. Mate both surfaces and apply mild pressure. once the intended surfaces are mated, it will not be possible to reposition them without breaking the bond. Membrane should be rolled when completed. CAUTION. Keep bonding adhesive out of the seam areas at all times!



SealTrust Roofing
1175 E. Diamond Avenue
Evansville, IN 47711

Phone: 812.868.0790
Fax: 812.868.0789

email: cs@sealcorpusa.com
www.sealtrustroofing.com