



TPO and Rubber Roofing Products

Pipe Boot Installation



Product Information:

Seal Trust™ Pipe Boots are pre-molded EPDM accessories for flashing pipes or stacks protruding through the EPDM roof. Pipe Boots are installed over vent stacks and pipes usually on flat roof surfaces. The boots all come pre-taped for easy installation with a flange that installs to the membrane in a peel and stick application. The boots come with two piece release paper for easy use.

Surface Preparation:

All surfaces need to be dry and free from oil, grease, talc, dust, dirt, and other foreign materials.

Application Instructions:

Always clean and prime membrane using roofing industry standard products for tape applications such as Seal Trust™ Tack Back™ Primer, Tape Primer, or Low VOC Primer. Usual installation requires primer installed on or about 4-5 inches away from each pipe. Then measure the diameter of the pipe and cut the boot at one size smaller than the pipe (i.e. 4" stack cut at 3" level) and stretching over the pipe. Before pipe boot installation, Water Cut Off caulk should be installed on the pipe for maximum protection. Pipe clamp is provided and required for final step which includes tightening the clamp and applying Lap Sealant on top of the clamp.



SealTrust Roofing
1175 E. Diamond Avenue
Evansville, IN 47711

Phone: 812.868.0790
Fax: 812.868.0789

email: cs@sealcorpusa.com
www.sealtrustroofing.com