



Rubber Roofing Products

EPDM PATCH KIT

INSTALLATION INSTRUCTIONS

USAGE:

The EPDM Patch Kit is an all-in-one solution to repair small holes or tears in EPDM rubber membrane. The kit can also be used for T-Patches (qty 4). The kit contains 4- 8" round cured EPDM Patches, 1 pint of Tape Primer, 1 Scrubbing pad and a Seam Roller.

Directions:

Clean and dry membrane. Scrub in Tape Primer using scrubber pad in an area slightly larger than the disk needs. Use gloves and eye protection. Allow the primer to flash off, or dry to the point that when touching the primed area with a finger, it feels tacky and no strings are visible.

Remove half of the paper backing from the disk and fold in half with the EPDM side facing itself.

Install one half of the disk onto the membrane starting in the center, then roll the rest of the exposed half down. This is to help prevent fish mouths or wrinkles. Remove the paper backing from the other half and lay down onto the membrane just like before.

Roll with a included roller to ensure a good bond between disk and membrane.